

• • MOBIL-PDi/MDi

ESYLUX

www.esylux.com

GB • REMOTE CONTROL MOBIL-PDi/MDi

Congratulations on your purchase of this high-quality ESYLUX product. To ensure proper operation, please read these user instructions carefully and keep them for future reference.

1 • SAFETY INSTRUCTIONS

Use this product only as intended (as described in the user instructions). Changes or modifications to the product or painting it will result in loss of warranty. Defective or damaged batteries should be recycled immediately.

2 • DESCRIPTION

The ESYLUX Mobil-PDi/MDi infrared remote control is compatible with ESYLUX presence sensors PD 360i/8, PDE 360i/8, PD 360i/8 mini, PD 360i/24, PDE 360i/24, PD 360i/Hallway, PDE 360i/Hallway, PD 180i/R, PD 360i/24 UC24V and ESYLUX motion detectors MD 360i/8 mini, MD 360i/24, MD 180i/R, MD 180i/T. It is used to easily set different parameters and special functions. With a range of approx. 5 - 6 m, quick and precise programming can be done without tools or a ladder. Wall mount for attaching remote control included.

3 • INITIAL OPERATION

A battery for the remote control is included in delivery. Remove the protective foil between battery and contact before initial use (fig. 1). For further information on programming, please refer to the operating instructions for the device you are setting up.

4 • BATTERY

If under normal conditions the range should fall off sharply or if remote adjustment is no longer possible, a weak or empty battery may be the reason for this. Replace the battery if necessary. Keep the locking mechanism pressed down while removing the battery holder (fig. 2). Make sure that the polarity is correct when putting in the new battery.



NOTE: The end consumer is legally required to properly return all used and spent batteries and accumulators. Do not put batteries in the regular trash (Council Directive 91/157/EEC).

5 • ESYLUX WARRANTY

ESYLUX products are tested in accordance with applicable regulations and manufactured with the utmost care. The duration of the warranty is based on statutory guidelines. The warranty can only be honoured if the appliance is sent back with the receipt, unchanged, packed and with sufficient postage to ESYLUX GmbH or to the relevant distributor in your country. (Visit www.esylux.com for a complete overview.) Please include a brief written description of the fault with any device you send back. If the warranty claim proves justified, ESYLUX GmbH will, within a reasonable period, either repair the device or replace it. If a claim is unfounded (e.g. because the warranty has expired or the fault is not covered by the warranty), then ESYLUX GmbH will attempt to repair the device for you in a cost-effective manner. The warranty does not apply to natural wear and tear, changes caused by environmental factors or damage in transit, nor to damage caused as a result of failure to follow the installation or user instructions. Any batteries or bulbs supplied with the device are not covered by the warranty. ESYLUX GmbH shall not be liable for any indirect, consequential or financial losses.

FIG. 1





FIG. 2



• TECHNICAL DATA

BATTERY	LITHIUM CR 2032 - 3 V
RANGE APPROX.	overcast/dark approx. 5 - 8 m, direct sunshine approx. 2 - 3 m
COLOR	Silver
DIMENSIONS	<p>Width 50 mm Height 100 mm Depth 9 mm</p>

Technical and design features may be subject to change.

ESYLUX

ESYLUX GmbH

Postfach 1834, 22908 Ahrensburg/Germany
Internet: www.esylux.com
e-mail: info@esylux.com